

Universal Master Flash®

INSTALLATION GUIDE

Universal Size and Trimming

Universal Pipe Range	Mini	#1	#2	#3	#4	#5	#6	#7	#8	#9
Closed 0" - 2" (0-50mm)	Closed Top	Closed Top	Closed Top	Closed Top	Closed Top	Closed Top	Closed Top	Closed Top	Closed Top	Closed Top
1 2-1/4" - 2-3/4" (57-70mm)	1 0" - 3/8" (0-9mm)	1 1/8" - 1-1/4" (31-31mm)	1 1-3/4" - 2" (45-51mm)	1 2-1/4" - 2-3/4" (57-70mm)	1 3" - 3-3/4" (75-95mm)	1 4-1/4" - 5" (108-127mm)	1 5" - 5-1/2" (125-140mm)	1 6" - 6-1/2" (150-165mm)	1 7" - 8" (175-195mm)	1 9" - 10" (225-254mm)
2 2-3/4" - 3-1/4" (70-83mm)	2 1/2" - 5/8" (12-15mm)	2 1-3/8" - 1-5/8" (34-41mm)	2 2-3/8" - 2-1/2" (60-65mm)	2 2-3/4" - 3-1/4" (70-83mm)	2 3-3/4" - 4-1/2" (95-114mm)	2 5" - 5-3/4" (127-146mm)	2 5-1/2" - 6" (140-155mm)	2 6-1/2" - 7" (165-180mm)	2 8" - 8-1/2" (195-210mm)	2 10" - 11" (254-279mm)
3 3-1/4" - 4" (90-102mm)	3 3/4" - 1" (19-25mm)	3 1-5/8" - 1-7/8" (41-47mm)	3 2-3/4" - 3" (70-76mm)	3 3-1/4" - 4" (90-102mm)	3 4-1/2" - 5-1/4" (114-133mm)	3 5-3/4" - 6-1/2" (146-165mm)	3 6" - 6-1/2" (150-165mm)	3 7" - 7-1/2" (180-195mm)	3 8-1/2" - 9" (210-225mm)	3 11" - 12" (279-304mm)
4 4" - 4-3/4" (102-121mm)				4 4" - 4-3/4" (102-121mm)	4 5-1/4" - 5-3/4" (133-146mm)	4 6-1/2" - 7" (165-180mm)	4 7-1/2" - 8" (195-210mm)	4 8-1/2" - 9" (210-225mm)	4 9-1/2" - 10" (240-255mm)	4 12" - 13" (304-330mm)
5 4-3/4" - 5" (121-127mm)				5 4-3/4" - 5" (121-127mm)	5 5-3/4" - 6-1/4" (146-160mm)	5 7" - 7-1/2" (175-190mm)	5 7-1/2" - 8" (190-205mm)	5 8-1/2" - 9" (210-225mm)	5 9-1/2" - 10" (240-255mm)	5 12" - 13" (304-330mm)
										5 15" - 16" (381-406mm)
										5 17" - 18" (431-457mm)
										5 18" - 20" (457-508mm)

* Note This is the #3 Universal For Reference

**Base Dimension: Mini 4" (101mm) | #1 4-3/4" (120mm) | #2 6-1/4" (158mm) | #3 7-3/4" (196mm) | #4 9-1/4" (234mm) | #5 10-1/2" (266mm) | #6 12-1/2" (317mm) | #7 14-1/2" (368mm) | #8 16-1/2" (412mm) | #9 25-1/4" (641mm)

• Find pipe size in table and trim Universal Master Flash® as shown on outline. • Use one size larger Universal Master Flash® on steep roofs or deep corrugation. • Cut the flashing at least 20% less than the pipe Outer Diameter

5 Easy Steps Installation Materials: Universal Master Flash® | Fasteners | Washers | Snips/Scissors | Measuring Tape | Marker/Pencil | Sealant



CUT MARKS

INSTALLATION GUIDES

